



HEWLETT-PACKARD CALCULATOR

Model 9100A

Operating and Programming





WARRANTY AND ASSISTANCE

The Hewlett-Packard 9100A Calculator is warranted against defects in material and workmanship. This warranty applies for one year from the date of delivery for calculators returned to the nearest HP field office. We will repair or replace parts which prove to be defective during the warranty period. No other warranty is expressed or implied. We are not liable for consequential damages.

For any assistance contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided on pages 32 and 33 of this manual.

OPERATING AND PROGRAMMING

HEWLETT PACKARD 9100A



GENERAL DESCRIPTION

This section contains general information about the Model 9100A. Included is a discussion of calculator performance checks, accessories supplied with the Model 9100A, and information concerning servicing.

The Hewlett-Packard 9100A Calculator is a scientific desktop calculator. Trigonometric and logarithmic functions are calculated with a single keystroke. The Model 9100A is programmable; conditional branch instructions provide complete programming capability. In addition, two programs can be recorded on each magnetic card supplied with the 9100A.

The Calculator has two memory systems. One is a unique Hewlett-Packard Read-Only-Memory. It contains the sub-routines necessary to execute the keyboard instructions and to calculate the trigonometric and logarithmic functions.

The 9100A also contains a magnetic core memory which adds the storage and programming features. There are 19 accessible registers in the magnetic core memory: three are displayed, two are only for data storage and 14 can be used for program storage or for additional data storage. The 14 program registers can accommodate up to 196 program steps.

Three registers are displayed on the cathode ray tube; they are designated x KEYBOARD, y ACCUMULATOR and z TEMPORARY. The format of the display can be selected on the keyboard. With Floating Point notation, the contents of the registers are displayed as a ten-digit number and a two-digit exponent, indicating the power of ten multiplier. This mode of display allows simultaneous presentation of very large (up to 10^{99}) and very small (down to 10^{-99}) numbers. With Fixed Point notation, the contents of the registers are displayed in decimal format, with the number of digits to the right of the decimal (0 to 9) set by the decimal thumbwheel. Regardless of the display mode selected, the 9100A operates in Floating Point calculating all answers to 12 digits, of which ten are displayed.

INITIAL INSPECTION

The calculator was carefully inspected both mechanically and electrically before shipment. It should be physically free of marks or scratches and in perfect electrical order upon receipt. To confirm this, the calculator should be inspected for physical damage in transit. Also check for supplied accessories listed in Table 1 (page 6), and test the electrical performance of the calculator.

A magnetic program card loaded with the Diagnostic Program (See page 28, for an explanation) is in the pocket on the rear cover of the Program library. To enter the program:

SET: 
 SET: 
 SET: 
 SET: 

PRESS:   

Be sure magnetic card is fully inserted in the card reader with the printed side of the card toward the keyboard.

PRESS: 

PRESS: 

Execution of the program (indicated by a flashing display of $X=3.$, $Y=2.000000$ and $Z=1.$) ensures that the 9100A is operating correctly.

If the calculator is damaged or an electrical deficiency is indicated, file a claim with the carrier or refer to the warranty on the inside front cover of this manual.

CAUTION
 USE A SOFT CLOTH TO CLEAN THE DISPLAY BEZEL. AN ABRASIVE MATERIAL WILL SCRATCH THE SURFACE.

POWER REQUIREMENTS

The Model 9100A requires either 115 or 230 volts ac $\pm 10\%$, 50 to 60 Hertz and 400 Hertz and requires less than 70 watts of power. With the calculator disconnected from the ac power source, slide the line voltage switch on the rear panel until the line voltage to be used appears.

CAUTION

DO NOT APPLY OPERATING POWER TO THE 9100A CALCULATOR UNLESS THE LINE VOLTAGE SWITCH ON THE REAR PANEL IS IN THE PROPER POSITION. OTHERWISE, DAMAGE TO POWER TRANSFORMER MAY RESULT.

GROUNDING REQUIREMENTS

To protect operating personnel, the National Electrical Manufacturers' Association (NEMA) recommends that the calculator keyboard and cabinet be grounded. The calculator is equipped with a three-conductor power cable which, when plugged into an appropriate receptacle, grounds the cabinet of the calculator. The round pin on the power cable three-prong connector is the ground connection.

The accessories and equipment supplied with each Model 9100A are listed in Table 1.

TABLE 1

Accessories/Equipment Supplied

PART NO.	QUANTITY	DESCRIPTION
09100-90001	2	Operating and Programming Manual
09100-90002	1	Program Library
09100-90003	1	Program Pad
09100-90004	1	Magnetic Program Card Loaded with Diagnostic Program
4040 - 0350	1	Dust Cover
5060 - 5919	1	Magnetic Program Card Container with Ten Program Cards
8120 - 0078	1	Power Cord
9320 - 1157	1	Pull-out Instruction Card contained in the bottom of the 9100A

A box of five program pads (Part No. 09100-90000) is available.

Service contracts are available for the 9100A Calculator. For further information contact your local Hewlett-Packard Sales and Service office. (See pages 32 and 33 for office locations.)

ACCESSORIES EQUIPMENT SUPPLIED

SERVICE CONTRACTS

KEYBOARD

7

Switches ac line power to the Calculator. Application of ac line power lights the register designators at the right of the cathode ray tube.



Selects the entry and display units for the trigonometric functions.



Selects the mode of operation.

RUN: used to perform calculations, address the program counter and execute a program.



PROGRAM: used to enter a program from the keyboard and verify a program.

Selects the mode of display.

FLOATING DECIMAL POINT: the display consists of a ten-digit number and a two-digit exponent, indicating the power of ten multiplier.



NUMBER

DISPLAY

12,345.67898 = 1.234567898×10^4 1.234 567 898 04

FIXED DECIMAL POINT: the number is displayed with the decimal point correctly located. The decimal wheel sets the number of places to the right of the decimal point. The least significant digit is rounded. If the number overflows to the left of the decimal point, the display for the overflowed register reverts to floating decimal point.

DECIMAL WHEEL SETTING

DISPLAY



12345.67898



12345.679

↑ ↑
Leading Zeros Last Digit
Blanked Rounded



Number too large for this setting - automatically shifts to floating decimal point.

The error light indicates an illegal operation such as division by 0., $\sqrt{-x}$, $\sin^{-1}x$ ($|x| > 1$), $\ln x$ ($x < 0$). An illegal operation during program execution will not stop the program.



NUMBER ENTRY

CLEAR

Clears the X, Y, Z, *e* and *f* registers (0. \rightarrow X,Y,Z,*e* and *f*). Clears the FLAG and clears the ARC and HYPER conditions.

CLEAR *x*

Clears the X register (0. \rightarrow X). Clears the ARC and HYPER conditions. It is not necessary to press CLEAR *x* before each entry.

**CHG
SIGN**

Changes the sign of the contents of the X register. Changes the sign of the exponent if ENTER EXP was pressed.



Sets the decimal point. It is not necessary to enter the decimal point when entering integers or when using the ENTER EXP key.

**ENTER
EXP**

Clears the exponent and causes the next digit entries (0 to 99) and CHG SIGN to affect only the exponent. The exponent digits are entered in a serial manner, with each new digit entry becoming the least significant digit of the exponent.

CLEAR **2** **ENTER
EXP** **1** **0**

0.	00
0.	00
2.	10

Pressing ENTER EXP after any keyboard operation, except digit entry, will enter 1.0 for the number in X.

CLEAR **ENTER
EXP** **CHG
SIGN** **6**

0.	00
0.	00
1.000	000 000-06

ALL KEYBOARD ENTRIES ARE DISPLAYED IN THE X REGISTER.

SET: **FLOAT**

ENTER: 126.78

CLEAR **1** **2** **6** **.**

0.	00
0.	00
1.267	02

7 **8** or

CLEAR **1** **2** **6** **7** **8** **ENTER
EXP** **2**

NUMBER ENTRY

9

SET: **FLOAT**

ENTER: $-39,800 = -3.98 \times 10^4$

CLEAR \times CHG SIGN 3 9 8 0 0 or

CLEAR \times 3 9 8 CHG SIGN ENTER EXP 4

0. 00
0. 00
-3.980 0 04

SET: **FIXED**

SET: Decimal wheel to 4

ENTER: .0094

CLEAR \times 9 4 ENTER EXP 3

CHG SIGN or

CLEAR \times . 0 0 9 4

0.
0.
.0094

SET: **FIXED**

SET: Decimal wheel to 4

ENTER: 128.0167

CLEAR \times 1 2 8 .

0 1 6 7

0.
0.
128.0167

SET: Decimal wheel to 3

0.
0.
128.017

SET: Decimal wheel to 8

0.
0.
1.280 167 02

SET: **FLOAT**

ENTER: -4×10^{-12}


CLEAR \times CHG SIGN 4 ENTER EXP CHG SIGN

1 2

0. 00
0. 00
-4. -12

CONTROL KEYS

The Control Keys reposition the contents of the displayed registers as required for succeeding calculations. x , y and z refer to the contents of X, Y and Z.




Duplicates the contents of X to the Y register and shifts the contents of Y to the Z register. Loses the contents of the Z register.




Duplicates the contents of Z to the Y register and shifts the contents of the Y register to the X register. Loses the contents of the X register.



Shifts the contents of X to the Y register, shifts the contents of Y to the Z register and shifts the contents of Z to the X register.



Shifts the contents of Z to the Y register, shifts the contents of Y to the X register and shifts the contents of X to the Z register.



Exchanges the contents of the X and Y registers. The contents of Z are unchanged.




ARITHMETIC KEYS

11


The arithmetic keys operate on the X and Y registers, entering the result of the calculation into the Y register and leaving the X register unchanged.

Adds the contents of the X register to the contents of the Y register. The sum is entered into the Y register and the X register is unchanged.

$$8 + 4 = 12 \rightarrow Y$$




$$6 + 7 + 4 = 17 \rightarrow Y$$




Subtracts the contents of the X register from the contents of the Y register. The difference is entered into the Y register and the X register is unchanged.

$$17 - 9 = 8 \rightarrow Y$$



$$47 - 19 - 8 + 5 = 25 \rightarrow Y$$



ARITHMETIC KEYS




Multiplies the contents of the Y register by the contents of the X register. The product is entered into the Y register and the X register is unchanged.

$$9 \times 7 = 63 \rightarrow Y$$



$$3 \times 5 \times 4 \div 8 = 7.5 \rightarrow Y$$




Divides the contents of the Y register by the contents of the X register. The quotient is entered into the Y register and the X register is unchanged.

$$36 \div 4 = 9 \rightarrow Y$$



$$72 \div 6 \div 3 + 9 = 13 \rightarrow Y$$



EXAMPLE
$$\frac{(3 \times 4) + (6 - 9)}{(8 \times 2) - 6} = .9 \rightarrow Y$$

STEP	KEY	STEP	KEY	STEP	KEY
1—	3	7—	9	13—	6
2—	↑	8—	—	14—	—
3—	4	9—	8	15—	↓
4—	X	10—	↑	16—	÷
5—	6	11—	2		
6—	+	12—	X		

CONTROL-STORAGE

13

The Storage and Recall Keys provide access to the 16 storage registers: 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, *a*, *b*, *c*, *d*, *e* and *f*. It is not necessary to clear a register before storing a number; write over the previously stored number.

Stores the contents of X in the register indicated by the following keystroke: 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, *a*, *b*, *c*, *d*, *e* or *f*. The contents of the X register are unchanged.



Stores the contents of Y in the register indicated by the following keystroke: 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, *a*, *b*, *c*, *d*, *e* or *f*. The contents of the Y register are unchanged.



CONTROL-RECALL


Press *a*, *b*, *c*, *d*, *e* or *f* to recall the contents of that register to the X register. The contents of *a*, *b*, *c*, *d*, *e* or *f* are unchanged. The *y*↔*x* key must be used to recall the contents of the numeric registers. Pressing only 0, 1, 2, 3, 4, 5, 6, 7, 8, 9 will not recall the contents of that register to the X register, but will enter that digit in the X register.

Recalls the contents of *f* and *e* to the X and Y registers. The contents of *f* and *e* are unchanged.



CONTROL-STORAGE AND RECALL

Exchanges the contents of Y with the contents of the register indicated by the following keystroke: 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, *a*, *b*, *c*, *d*, *e* or *f*. This is the only instruction that recalls the contents of a numeric storage register.



FUNCTION KEYS

DEGREES

RADIANS

Selects the entry and display units for the trigonometric functions. To convert from **DEGREES (RADIANS)** to **RADIANS (DEGREES)**:

- 1) SET: **DEGREES (RADIANS)**
- 2) ENTER: **DEGREES (RADIANS)**
- 3) PRESS: $\sin x$, $\cos x$, $\tan x$
- 4) SET: **RADIANS (DEGREES)**
- 5) PRESS: $\overset{\text{arc}}{\nabla} \sin x$, $\cos x$, or $\tan x$; answer in **RADIANS (DEGREES)** is entered into the X register.

Inverse trigonometric functions are calculated for the principal value of the function.

$$\theta = \sin^{-1}x; -90^\circ \leq \theta \leq +90^\circ; (-\pi/2 \leq \theta \leq +\pi/2)$$

$$\theta = \cos^{-1}x; 0^\circ \leq \theta \leq +180^\circ; (0 \leq \theta \leq \pi)$$

$$\theta = \tan^{-1}x; -90^\circ \leq \theta \leq +90^\circ; (-\pi/2 \leq \theta \leq +\pi/2)$$

EXAMPLE

$$\sin +135^\circ = +.7071; \sin^{-1}+.7071 = +45^\circ$$

 $\sin x$

Replaces the contents of the X register with the Sine of the contents of X.

 $\cos x$

Replaces the contents of the X register with the Cosine of the contents of X.

 $\tan x$

Replaces the contents of the X register with the Tangent of the contents of X.

 $\overset{\text{arc}}{\nabla}$

Prefix used to calculate the inverse trigonometric and hyperbolic functions. The answer is entered into the X register.

 $\text{hyper} \nabla$

Prefix used to calculate the hyperbolic (\sinh , \cosh , and \tanh) functions. The answer is entered into the X register.

EXAMPLE: $\sinh^{-1} 2 = 1.4436$

CORRECT

$$\sinh^{-1} 2 \rightarrow X$$

INCORRECT

$$\sin^{-1} 2 \rightarrow \text{ERROR LIGHT}$$

FUNCTION KEYS

15

Replaces the contents of the X register with the square root of the contents of X.



Replaces the contents of the X register with the logarithm to the base e of the contents of X.



Replaces the contents of the X register with e raised to the power defined by the contents of X.




Replaces the contents of the X register with the logarithm to the base 10 of the contents of X.



Integer x . Eliminates the decimal part of the contents of the X register. Enters the integer into the X register.



Absolute value of y . Sets the contents of the Y register positive.



Enters pi into the X register.



VECTOR KEYS

Conversion from rectangular to polar coordinates will calculate the angle, θ , in the range:

$$-180^\circ < \theta \leq +180^\circ$$

$$-\pi \text{ radians} < \theta \leq +\pi \text{ radians}$$


TO
POLAR

Changes rectangular coordinates consisting of an x component in the X register and a y component in the Y register to polar coordinates:

$$\text{Angle } (\theta) = \tan^{-1} y/x \rightarrow Y$$

$$\text{Radius } (R) = \sqrt{x^2 + y^2} \rightarrow X$$

SET: DEGREES



CLEAR

4

CHG
SIGN



3

TO
POLAR

0.
-53.1301
5.

TO
RECT

Changes polar coordinates consisting of a radius (R) in the X register at an angle (θ) in the Y register to rectangular coordinates:

$$y \text{ component} = R \times \sin \theta \rightarrow Y$$

$$x \text{ component} = R \times \cos \theta \rightarrow X$$

CLEAR

2

2

5



2

\sqrt{x}

TO
RECT

0.
-1.0000
-1.0000

VECTOR KEYS

17

ACCUMULATE +: Adds the contents of the X and Y registers to the contents of the *f* and *e* registers respectively. The sums are entered into the *f* and *e* registers. *f* and *e* are cleared with the CLEAR instruction.

$$f + X \rightarrow f$$

$$e + Y \rightarrow e$$

ACCUMULATE -: Subtracts the contents of the X and Y registers from the contents of the *f* and *e* registers respectively. The differences are entered into the *f* and *e* registers.


$$f - X \rightarrow f$$

$$e - Y \rightarrow e$$

Recalls the contents of the *f* and *e* registers to the X and Y registers respectively. The contents of *f* and *e* are unchanged.

$$f \rightarrow X$$

$$e \rightarrow Y$$



EXAMPLE: Vector Addition

$$(2x + 3y) + (4x + 5y) - (3x - 6y) = 3x + 14y$$

STEP	KEY	STEP	KEY	STEP	KEY
1—	CLEAR	6—	5	11—	CHG SIGN
2—	3	7—	↑	12—	↑
3—	↑	8—	4	13—	3
4—	2	9—	ACC +	14—	ACC -
5—	ACC +	10—	6	15—	RCL

EXAMPLE: Multiplication of complex numbers ($j^2 = -1$)

$$(3 + j4)(-2 + j3) = -18 + j1$$

STEP	KEY	STEP	KEY	STEP	KEY
1—	CLEAR	7—	ACC +*	13—	ln x
2—	4	8—	3	14—	ACC +
3—	↑	9—	↑	15—	RCL
4—	3	10—	2	16—	e^x
5—	TO POLAR	11—	CHG SIGN	17—	TO RECT
6—	ln x	12—	TO POLAR		

PROGRAMMING

The Hewlett-Packard Model 9100A has a maximum capacity of 196 program steps. The 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, *a*, *b*, *c*, and *d* registers can be used for either program or data storage. The X, Y and Z registers are the display registers and the *e* and *f* registers are only data storage registers; these five registers cannot be used for program storage.

Program storage consists of a 14 by 14 array (see Figure 1). The registers are designated 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, *a*, *b*, *c*, and *d* as are the characters in each register. Memory address *c*2 indicates the *c* register and character 2 in the *c* register.

A program is stored so that the register with the starting address of the program is filled with the program steps before the next sequential register is entered to store program steps. With the first program step in location 00, program storage will be used in the following manner: 00, 01, . . . 09, 0*a*, 0*b*, 0*c*, 0*d*, 10, . . . 19, 1*a*, 1*b*, 1*c*, 1*d*, 20 . . . up to *dc*, *dd*, the address at which the program counter resets to 00.

It is not necessary to learn a program language for the Calculator. Keyboard operations are the program instructions. Each program step is one keyboard instruction.

Programs that require more storage than the *e* and *f* registers necessitate use of a register that could be used for program storage. A complete register is required for storing a ten-digit number and the two-digit exponent; therefore, the maximum program size of 196 steps is reduced by 14 steps for each program register used for data storage.

	CHARACTER													
	0	1	2	3	4	5	6	7	8	9	<i>a</i>	<i>b</i>	<i>c</i>	<i>d</i>
REGISTER	0													
	1													
	2												<i>c</i> 2	
	3													
	4													
	5													
	6	Program or Data Storage												
	7													
	8													
	9													
	<i>a</i>													
	<i>b</i>													
	<i>c</i>													
	<i>d</i>													
<i>e</i>	Data Storage													
<i>f</i>														
<i>x</i>	Display													
<i>y</i>														
<i>z</i>														

Figure 1

PROGRAMMING

19

Selects the mode of operation.

RUN: used to perform calculations, address the program counter and execute a program.

PROGRAM: used to enter a program from the keyboard and verify a program.

Causes an unconditional branch to the program address entered by the next two keystrokes or by the next two program steps. Each program step can be only one keystroke.

CORRECT		INCORRECT	
STEP	KEY	STEP	KEY
29	GO TO () ()	29	GO TO () ()
2a	5	2a	5 C
2b	C	2b	

Starts program execution at the present address. If the program has halted execution at a STOP instruction, pressing CONTINUE will start program execution with the next program step. If the program has halted execution at an END instruction, pressing CONTINUE will start program execution at program step 00. CONTINUE can also be used as a 'no operation' program step. See the program for N!, page 26.

Halts program execution and causes a return to the display mode. The STOP instruction provides an unconditional halt of program execution for entry of data or display of results. Pressing CONTINUE begins program execution with the next program step. Pressing STOP during execution of a program will cause the program to stop execution at the present program step and will cause a return to the display mode. Pressing CONTINUE will begin program execution with the next program step.

Use the STOP instruction to enter data. With the program at a STOP or END instruction any keyboard operation can be manually executed, provided that no data is stored in a register containing program steps. Storing data in a register containing program steps will destroy the program steps in that register.

Halts program execution and causes a return to the display mode. The instruction resets the program counter to 00 so that pressing CONTINUE begins program execution at step 00.

END must be the last instruction in a program. Reading the END instruction from the magnetic card stops the reading process and resets the program counter to 00.

PROGRAM

RUN

GO TO
() ()

CONTINUE

STOP

END

PROGRAMMING

PROBLEM: Write a program to solve $\frac{A \times B}{A + B}$ for any A and B.

STEP	KEY	x	y	z	f	e	
00	CLEAR	0	0	0	0	0	Clear display & e & f.
01	STOP	A	B				Stop to enter A & B.
02	$x \rightarrow ()$						
03	e					A	
04	$y \rightarrow ()$						Store A and B.
05	f	A	B	0	B		
06	x		AxB				
07	↑		A	AxB			Move AxB to Z to calculate A + B.
08	f	B					
09	+		A+B				
0a	ROLL ↓	A+B	AxB	B			Position AxB and A+B to calculate quotient.
0b	÷		$\frac{AxB}{A+B}$				
0c,,	ROLL ↑	B	A+B	$\frac{AxB}{A+B}$			
0d	$x \leftrightarrow y$		B				
10	e	A					
11	END	A	B	$\frac{AxB}{A+B}$			Final Display

See ENTERING A PROGRAM-FROM THE KEYBOARD (Page 24). A blank register indicates the contents of the register are unchanged from the previous step.

Causes a brief display before continuing with execution of the program. If the PAUSE key is held depressed during execution of a program, a STOP will occur at the next PAUSE instruction in the program. Pressing CONTINUE will begin execution with the next program step. Use successive PAUSE instructions for a longer display.

This instruction single-steps the program. The display will depend upon the mode of operation: PROGRAM or RUN. This is the only instruction that cannot be a program step.

PROGRAM: Single-steps the program, displaying in X the program step address and the code of the instruction in that program step.

EXAMPLE:

5.
4.
1.2----- 54

Program step 12 contains the SET FLAG instruction; its code is 54.

PAUSE

STEP
PRGM

RUN: Single-steps execution of the program displaying the contents of the X, Y, and Z registers after each step. Enter data at the proper program step to check operation of the program.

Each STEP PRGM keystroke executes the three steps of a GO TO () () and executes the conditional branch instructions in the following manner:

CONDITION MET

Conditional branch with an address in the next two program steps.

Executes the conditional branch and branches to the given address.

Conditional branch with instructions in the next two program steps.

Executes the conditional branch and the next instruction.

CONDITION NOT MET

Branches to and executes the third step following the conditional branch instruction.

NOTE

To verify a program with RUN selected, replace each CONTINUE instruction with either a PAUSE or STOP instruction. If a CONTINUE instruction is encountered, the Calculator will begin execution of the program.

Print the contents of X, Y or Z or any combination as selected on the printer. If no printer is being used, the PRINT instruction will act as the STOP instruction.



The FORMAT instruction controls the accessory output devices. If no accessory output device is being used, the FORMAT instruction will act as the STOP instruction. For complete information, see the Operating and Service Manual for the particular accessory.



PROGRAMMING

IF
 $x < y$

IF
 $x = y$

IF
 $x > y$

These instructions cause a conditional branch to one of two program locations dependent upon the contents of the X and Y registers. If the condition tested is met, the program will either branch to the address stored in the next two program steps or, if no address is given, execute the instructions in the next two program steps, and continue with the third program step following the conditional branch instruction. If the condition tested is not met, the program branches to and executes the third program step following the conditional branch instruction.

If the contents of $X = 6$, and the contents of $Y = 5$, the condition (IF $X > Y$) is met. The program will branch to step 08, the address given in steps 03 and 04, and enter 1. in the X and Y registers. If the contents of $X = -5$, and the contents of $Y = -2$, the condition is not met. The program will branch to step 05 and enter 2. in the X and Y registers.

STEP	KEY
00	CLEAR
01	STOP
02	IF $x > y$
03	0
04	8
05	2

STEP	KEY
06	↑
07	STOP
08	1
09	↑
0A	END

If the contents of X and Y are equal, the condition (If $X = Y$) is met. The program will execute steps 03 and 04 and continue with step 05, calculate $x^2 + y^2$ (See TO POLAR, page 16) and enter the answer into X. If the contents of X and Y are not equal the program will branch to step 05, calculate the product of $X \times Y$ and enter it into X.

STEP	KEY
00	CLEAR
01	STOP
02	IF $x = y$
03	TO POLAR

STEP	KEY
04	↑
05	X
06	↓
07	END

IF
FLAG

SET
FLAG

This instruction causes a conditional branch to one of two program steps depending upon whether or not the FLAG was set either manually or by a program step with the SET FLAG instruction. The condition is met if the FLAG was set. Branching after the IF FLAG instruction is the same as for the conditional branch instructions given above. The instruction also clears the FLAG.

Set the FLAG condition which is tested by the conditional branch instruction IF FLAG. This instruction and the IF FLAG instruction allow the operator to control program execution by either manual entry or program step entry of the SET FLAG instruction.

PROBLEM: Calculate the average value (\bar{X}) of N data points, x_i . Use the SET FLAG to indicate entry of the last data point.

SOLUTION

STEP	KEY
00	CLEAR
01	1
02	↑
03	STOP
04	IF FLAG
05	0
06	b
07	ACC +
08	GO TO () ()
09	0
0a	1
0b	RCL
0c	$x \rightarrow y$
0d	÷
10	END

ENTER PROGRAM

PRESS: GO TO (0) (0) (or END)

PRESS: CONTINUE

ENTER DATA: $x_i \rightarrow X$

PRESS: CONTINUE

After Last Data Entry,

PRESS: SET FLAG

PRESS: CONTINUE

Display:

$\bar{X} \rightarrow Y$
 $n \rightarrow X$

NOTE

The only sequence of instructions after a conditional branch instruction which will not give the expected results is a numeric or alphabetic instruction followed by a non-arithmetic or non-alphabetic instruction. The program will branch to the address (J) (K) given by the numeric or alphabetic instruction (J) and the second digit (K) of the address of the third instruction following the conditional branch instruction. The program will also execute the instruction in the second program step following the conditional branch instruction.

EXAMPLE:

STEP	KEY
04	IF $x < y$
05	2
06	ROLL ↓
07	÷

If the contents of $X = 3$, and the contents of $Y = 5$, the condition (IF $X < Y$) is met; the program will continue to step 05. The ROLL ↓ instruction will be executed and the program will then branch to step 27 (determined by the 2 in step 05 and the second digit of the address in step 07) rather than entering 2 in the X register and performing the ROLL ↓.

ENTERING A PROGRAM

FROM THE KEYBOARD

1. SET: **RUN**
2. PRESS*: **GO TO** (Starting Address)
3. SET: **PROG**
4. Press keys in program sequence.
5. SET: **RUN**
6. PRESS*: **GO TO** (Starting Address)

The program will execute the instruction in the starting address when CONTINUE is pressed.

7. Enter data and press CONTINUE as necessary for program execution.

When entering a program, the address for the instruction entered and the code of that instruction are displayed in the X register.

0.	00
0.	00
2.C	57

Step 2C contains the instruction.

PAUSE

FROM A MAGNETIC CARD

1. SET: **RUN**
2. PRESS*: **GO TO** (Starting Address)
3. Insert card, press: **ENTER**
4. PRESS*: **GO TO** (Starting Address)
5. Enter data and press CONTINUE as necessary for program execution.

NOTE

When entering or recording a program:

- 1) Hold the ENTER or RECORD key pressed until the card is partially ejected from the card reader.
- 2) The contents of Y and Z are unchanged.
- 3) ENTER: contents of X unchanged.
RECORD: contents of X destroyed.

See "CORRECTING A PROGRAM STEP" (Page 25) if an incorrect instruction is entered in the program.

* NOTE

Any address can be used for the first program step. However, a beginning address of 0.0 is generally used because of the convenience provided by the END instruction. Core storage is usually used beginning at the top (location 0.0) for program storage and beginning at the bottom (register F) for data storage.

RECORDING A PROGRAM

Two programs can be recorded on each magnetic card. The programs are designated A and B. To read or record program A, insert the card with the A arrow pointing down and the printed side of the card toward the keyboard. To read or record program B, insert the card in the same manner with the B arrow pointing down.

1. SET: **RUN**
2. PRESS: **GO TO** (Starting Address)
3. INSERT CARD, PRESS: **RECORD**

To permanently save a program recorded as program A or B, cut off the corner of the card along the tip of the A or B arrow.



VERIFYING A PROGRAM

After a program is entered in storage it can be verified by selecting either the PROGRAM or RUN mode of operation.

PROGRAM

1. SET: **RUN**
2. PRESS: **GO TO (11)** **Starting Address**
3. SET: **PROG**
4. Each STEP PRGM key-stroke will increment the program counter. The X register will display the program step address and the code of the instruction in that location.

```
0.      00
0.      00
8.9 ----- 70
```

Step 89 contains the sin x instruction.

RUN

1. SET: **RUN**
2. PRESS: **GO TO (11)** **Starting Address**
3. Each STEP PRGM key-stroke will single-step the program, displaying the contents of the X, Y, and Z registers. Enter data at the correct program step to check operation and solution of the program. While editing, replace every CONTINUE instruction with a PAUSE or STOP instruction. Encountering a CONTINUE instruction while editing in the RUN mode of operation will cause the Calculator to begin automatic execution of the program.

The key codes are given on page 3 and on the pull-out instruction card.

CORRECTING A PROGRAM STEP

1. SET: **RUN**
2. PRESS: **GO TO (11)** **Step to be changed**
3. SET: **PROG**
4. ENTER CORRECT INSTRUCTION.
5. a. TO CONTINUE EDITING:
PRESS: **STEP PRGM**
b. TO EXECUTE PROGRAM:
SET: **RUN**
PRESS: **GO TO (11)** **Starting Address**

PROGRAMMING

CALCULATE N FACTORIAL (N!)

STEP	KEY	x	y	z	f	e
00	CLEAR	0	0	0	0	0
1	STOP	N	ENTER N → X			
2	$x \rightarrow ()$					
3	f				N	
4	IF $x=y$					
5	CONTINUE					
6	1	1				
7	↑	N	N			
8	↑	N	N	N		
9	1	1				
a	—	1	N'-1	N'		
b	IF $x > y$					
c	1					
d	6					
10	ROLL ↓	N'-1	N'	1		
1	X		N'(N'-1)			
2	ROLL ↑	1	N'-1	N'(N'-1)		
3	GO TO () ()					
4	0					
5	a					
6	0	0	N'-1	N!		
7	ROLL ↓	N'-1	N!	0		
8	f	N	N!	0		
9	END	N	N!	0	- DISPLAY -	


A blank register indicates the contents of the register are unchanged from the previous step.

CALCULATE N FACTORIAL (N!)

$$N! = N (N - 1) (N - 2) \dots (N - N + 2) (1)$$

$$6! = (6) (5) (4) (3) (2) (1) = 720$$

$$0! = 1$$



The IF $X=Y$ is met at step 04 if $N = 0$; set $0! = 1$. N' is the partial product calculation. Each IF $X > Y$ at step 0b not met develops next partial product. After 1st pass, $N' = N (N - 1)$. After 2nd pass, $N' = N (N - 1) (N - 2)$

DIAGNOSTIC PROGRAM

The Diagnostic Program exercises every subroutine in the Calculator by program step entry of instructions rather than keyboard entry. Proper operation of the Calculator and the Diagnostic Program is indicated by a flashing display: $X = 3.$, $Y = 2.0000$, $Z = 1$.

Symptoms of improper operation are no display or a fixed display, indicating that program execution has stopped. To determine the program step at which the program stopped,

SET: **PROG**

PRESS: **STEP
PRGM**

The program step displayed in X is the step following the program step at which the STOP occurred. Single-step the program from the last error check (previous STOP instruction in the program) to the program step where the error was detected. If all instructions are correct, single-step the entire program.

No data entry is necessary for program operation. To run the program:

SET: **ON**

SET: **RUN**

SET: **RADIANS**

SET: **FIXED**

PRESS: **GO TO
() ()** **0** **0**

The Diagnostic Program is listed in the Program Library under Miscellaneous.

INSERT CARD IN THE CARD READER WITH THE PRINTED SIDE TOWARD THE KEYBOARD.

PRESS: **ENTER**

PRESS: **C
O
N
T
I
N
U
E**

PROGRAMMING TECHNIQUES

29

During program execution a constant can be entered in the X register by program step entry rather than using a complete register to store the constant and recalling it when needed.

STEP	KEY
22	ROLL ↑
23	2
24	.
25	1
26	3
27	X

After program step 26 is executed, 2.13 will be in the X register.

ENTERING A CONSTANT

PROBLEM: Calculate $\sqrt{P^2 + Q^2}$

$\sqrt{\text{SUM OF THE SQUARES}}$

KEY
ENTER P
↑
X
ENTER Q
↑
X
↓
+
↓
\sqrt{x}
$\sqrt{P^2 + Q^2} \rightarrow X$

KEY
ENTER P
↑
ENTER Q
TO POLAR
$\sqrt{P^2 + Q^2} \rightarrow X$

PROGRAMMING TECHNIQUES

SPLITTING A REGISTER

PROBLEM: Save a storage register by storing two integers, P and Q, in one register.

KEY
ENTER P
↑
ENTER Q
↑
ENTER 10. { 1
 0
 ÷
 ↓
 +
 y→() } P+Q/10
 f } →Y, f.

For P = 8,
Q = 9; 8.9 → Y, f

KEY
ENTER P
↑
1
↑
ENTER Q
÷
↓
+
y→() } P+1/Q
f } →Y, f

For P = 5,
Q = 4; 5.25 → Y, f.

To Obtain P and Q

KEY
f
↑
int x
—
x↔y
↑
ENTER 10. { ENTER
 EXP
 1
 x
P → Z, Q → Y

KEY
f
↑
int x
—
x↔y
↑
1
x↔y
÷
P → Z, Q → Y

PROBLEM: Calculate $\sum (-1)^n f_n(X)$

First Term Positive

First Term Negative

FLAG NOT SET ON FIRST PASS

STEP	KEY
00	
01	Calculate
...	$f_n(X)_n$ in
...	X or Y.
42	IF FLAG
43	4
44	8
45	SET FLAG
46	ACC +
47	ACC +
48	ACC -

STEP	KEY
00	
01	Calculate
...	$f_n(X)_n$ in
...	X or Y.
42	IF FLAG
43	4
44	8
45	SET FLAG
46	ACC -
47	ACC -
48	ACC +

Pressing ENTER EXP causes the following CHG SIGN and digit entries to be entered as the exponent of X. After ENTER EXP is pressed, pressing the decimal point key will return the control of the CHG SIGN and digit keys to the number in X.

3	ENTER EXP	CHG SIGN	4	0.	00
				0.	00
				3.	-04

CHG SIGN	9	8	0.	00
			0.	00
			-3.98	-04

Any number with an absolute value of less than 1×10^{-9} must be entered using the ENTER EXP key. It cannot be entered in decimal format.

For example, 1×10^{-10} :

.	0	0	0	0	0	0	0
0	0	1	<div><div>0.</div><div>0.</div><div>1.</div></div> <div><div>00</div><div>00</div><div>-00</div></div>				

The *e* and *f* registers can be used for program steps. However, each must be addressed with a GO TO (*e*) (0) or a GO TO (*f*) (0) to enter program steps. *e*0 is displayed as $-.0$ and *f*0 is displayed as 1.0 . The step following *e*0 is *a*0 and following *f*0 is *c*0. Branching to any other address requires direct branching with the GO TO () () and address instructions as the last three steps in either *e* or *f*. Program steps in the *e* and *f* registers cannot be recorded on the magnetic card.

USE OF THE FLAG

NUMBER ENTRY

ADDITIONAL PROGRAM STORAGE

HEWLETT • PACKARD SALES AND SERVICE

UNITED STATES

ALABAMA

P.O. Box 4207
2003 Byrd Spring Road S.W.
Huntsville 35802
Tel: (205) 881-4591
TWX: 810-726-2204

ARIZONA

3009 North Scottsdale Road
Scottsdale 85251
Tel: (602) 945-7601
TWX: 910-950-1282

282 South Tucson Boulevard
Tucson 85716
Tel: (602) 623-2564
TWX: 910-952-1187

CALIFORNIA

3519 Lankershim Boulevard
North Hollywood 91604
Tel: (213) 877-1282
TWX: 910-499-2170

1161 Embury Avenue
Palo Alto 94303
Tel: (415) 327-6500
TWX: 910-373-1280

2591 Carlsbad Avenue
San Antonio 78221
Tel: (512) 482-1463
TWX: 910-967-0092

7054 Shattuck Street
San Diego 92106
Tel: (619) 233-8103
TWX: 910-335-2006

COLORADO

2945 East Prentice
Englewood 80110
Tel: (303) 771-3455
TWX: 910-915-0705

CONNECTICUT

508 Island Street
East Hartford 06108
Tel: (203) 289-9394
TWX: 710-425-3416

111 East Avenue

Norwalk 06851
Tel: (203) 853-1251
TWX: 710-468-3750

DELAWARE

3941 Kennett Pike
Wilmington 19807
Tel: (302) 655-6161
TWX: 510-869-2214

FLORIDA

P.O. Box 545
Suite 106
9999 N.E. 2nd Avenue
Miami Shores 33153
Tel: (305) 758-3626
TWX: 810-848-7262

P.O. Box 20007
Herndon Station 32814
621 Commonwealth Avenue
Orlando
Tel: (305) 841-3970
TWX: 810-850-0113

P.O. Box 8128
Madera Beach 33708
410 150th Avenue
St. Petersburg
Tel: (813) 391-0211
TWX: 810-863-0366

GEORGIA

P.O. Box 28234
450 Interstate North
Atlanta 30328
Tel: (404) 436-6181
TWX: 810-766-4890

ILLINOIS

5500 Howard Street
Skokie 60076
Tel: (312) 677-0400
TWX: 910-223-3613

INDIANA

4002 Meadows Drive
Indianapolis 46205
Tel: (317) 546-4891
TWX: 810-341-3263

LOUISIANA

P.O. Box 856
1942 Williams Boulevard
Kenner 70062
Tel: (504) 721-6201
TWX: 810-955-5524

MARYLAND

6707 Whitestone Road
Baltimore 21207
Tel: (301) 944-5400
TWX: 710-862-0850

MASSACHUSETTS

P.O. Box 1648
2 Choke Cherry Road
Rockville 20850
Tel: (301) 948-6370
TWX: 810-828-9684

MICHIGAN

24315 Northwestern Highway
Southfield 48075
Tel: (313) 353-9100
TWX: 810-232-1532

MINNESOTA

2459 University Avenue
St. Paul 55114
Tel: (612) 645-9461
TWX: 910-563-3734

MISSOURI

9208 Wyoming Place
Kansas City 64114
Tel: (816) 333-2445
TWX: 910-771-2087

2812 South Brentwood Blvd.

St. Louis 63144
Tel: (314) 644-0220
TWX: 910-760-1670

NEW JERSEY

W. 120 Century Road
Paramus 07652
Tel: (201) 265-5000
TWX: 710-990-4951

1050B N. Kings Highway
Cherry Hill 08034
Tel: (609) 667-4000
TWX: 710-892-4945

NEW MEXICO

P.O. Box 8366
Station C
6501 Lomas Boulevard N.E.
Albuquerque 87108
Tel: (505) 255-5586
TWX: 910-989-1665

156 Wyatt Drive
Las Cruces 88001
Tel: (505) 526-2485
TWX: 910-983-0550

NEW YORK

1702 Central Avenue
Albany 12205
Tel: (518) 869-8462
TWX: 710-441-8270

1219 Campville Road
Endicott 13764
Tel: (607) 754-0050
TWX: 510-252-0890

82 Washington Street
Poughkeepsie 12601
Tel: (914) 454-7330
TWX: 510-248-0012

39 Saginaw Drive
Rochester 14623
Tel: (716) 473-9500
TWX: 510-253-5981

1025 Northern Boulevard

Roslyn, Long Island 11576
Tel: (516) 869-8400
TWX: 510-223-0811

NORTH CAROLINA

5858 East Molloy Road
Syracuse 13211
Tel: (315) 454-2486
TWX: 710-541-0482

NORTH CAROLINA

P.O. Box 5187
1923 North Main Street
High Point 27262
Tel: (919) 882-6873
TWX: 510-926-1516

OHIO

5579 Pearl Road
Cleveland 44129
Tel: (216) 884-9209
TWX: 910-421-8500

3460 South Dixie Drive
Dayton 45439
Tel: (513) 298-0351
TWX: 810-459-1925

OKLAHOMA

2919 United Founder Boulevard
Oklahoma City 73112
Tel: (405) 848-2801
TWX: 910-830-6862

OREGON

Westhill Mall, Suite 158
4475 S.W. Scholls Ferry Road
Portland 97225
Tel: (503) 292-9171
TWX: 910-464-6103

PENNSYLVANIA

2500 Moss Side Boulevard
Monroeville 15146
Tel: (412) 271-0724
TWX: 710-797-3650

144 Elizabeth Street

West Conshohocken 19428
Tel: (215) 248-1600, 828-6200
TWX: 510-660-8715

TEXAS

P.O. Box 1270
201 E. Arapaho Rd.
Richardson 75080
Tel: (214) 231-1601
TWX: 910-867-4723

P.O. Box 22813
4242 Richmond Avenue
Houston 77027
Tel: (713) 267-2407
TWX: 910-881-2645

GOVERNMENT CONTRACT OFFICE

225 Billy Mitchell Road
San Antonio 78226
Tel: (512) 434-4171
TWX: 910-871-1170

UTAH

2890 South Main Street
Salt Lake City 84115
Tel: (801) 486-8166
TWX: 910-925-5681

VIRGINIA

P.O. Box 6514
2111 Spencer Road
Richmond 23230
Tel: (703) 282-5451
TWX: 710-956-0157

WASHINGTON

433-108th N.E.
Bellevue 98004
Tel: (206) 454-3971
TWX: 910-443-2303

FOR U.S. AREAS NOT LISTED:

Contact the regional office nearest you: Atlanta, Georgia... North Hollywood, California... Paramus, New Jersey... Skokie, Illinois. Their complete addresses are listed above.

CANADA

ALBERTA

Hewlett-Packard (Canada) Ltd.
1745 Jasper Ave.
Edmonton
Tel: (403) 482-5561
TWX: 610-831-2431

BRITISH COLUMBIA

Hewlett-Packard (Canada) Ltd.
304-1037 West Broadway
Vancouver 9
Tel: (604) 738-5301
TWX: 610-922-5059

MANITOBA

Hewlett-Packard Co. Ltd.
511 Bradford Ct.
St. James
Winnipeg
Tel: (204) 786-7581

NOVA SCOTIA

Hewlett-Packard (Canada) Ltd.
7001 Mumford Road
Suite 356
Halifax
Tel: (902) 455-0511
TWX: 610-271-4482

ONTARIO

Hewlett-Packard (Canada) Ltd.
880 Lady Ellen Place
Ottawa 3
Tel: (613) 722-4223
TWX: 610-562-1952
Telex: 01-20607

Hewlett-Packard (Canada) Ltd.
1415 Lawrence Avenue West
Toronto
Tel: (416) 249-9196
TWX: 610-492-2382

QUEBEC

Hewlett-Packard (Canada) Ltd.
275 Hymus Boulevard
Pointe Claire
Tel: (514) 697-4232
TWX: 610-422-3022
Telex: 01-20607

FOR CANADIAN AREAS NOT LISTED:

Contact Hewlett-Packard (Canada) Ltd. in Pointe Claire, at the complete address listed above.

CENTRAL AND SOUTH AMERICA

ARGENTINA

Hewlett-Packard Argentina
S.A. C. I.
Lavalle 1171 - 3
Buenos Aires
Tel: 35-0436, 35-0627, 35-0431
Telex: 612-1069

BRAZIL

Hewlett-Packard Do Brasil
L. E. C. Ltda.
Rua Coronel Oscar Porto, 591
Sao Paulo - 8, SP
Tel: 71-1503
Cable: HEWPAK Sao Paulo

Hewlett-Packard Do Brasil
L. E. C. Ltda.
Avenida Franklin Roosevelt 84-
grupo 203
Rio de Janeiro, ZC-39, GB
Tel: 32-9733
Cable: HEWPAK Rio de Janeiro

CHILE

Hector Calcagni P.
Casilla 13942
Estado 215 - Oficina 1016
Santiago
Tel: 31-890, 490-505

COLOMBIA

Instrumentacion
Henrik A. Langebaek & Cia. Ltda.
Carrera 7 #48-59
Apartado Aereo 6287
Bogota, I D.E.
Tel: 45-78-06, 45-95-46
Cable: AARIS Bogota

COSTA RICA

Lic. Alfredo Gallegos Gudián
Apartado 3243
San José
Tel: 21-86-13
Cable: GALGUR San José

ECUADOR

Laboratorios de Radio-Ingenieria
Calle Guayaquil 1246
Post Office Box 3199
Quito
Tel: 12496
Cable: HOKVATH Quito

EL SALVADOR

Electronica
Apartado Postal 1589
27 Avenida Norte 1133
San Salvador
Tel: 25-74-50
Cable: ELECTRONICA
San Salvador

GUATEMALA

Olander Associates Latin America
Apartado 1226
7a. Calle, 0-22, Zona 1
Guatemala City
Tel: 22812
Cable: OLALA Guatemala City

MEXICO

Hewlett-Packard Mexicana, S.A.
de C.V.
Apartado Postal 12-832
Eugenia 408, Dept. 1
Mexico 12, D.F.
Tel: 43-03-79, 36-08-78

NICARAGUA

Roberto Terán G.
Apartado Postal 689
Edificio Terán
Managua
Tel: 3451, 3452
Cable: ROTERAN Managua

PANAMA

Electronica Balboa, S.A.
P.O. Box 4929
Ave. Manuel Espinosa No. 13-50
Bldg. Alina
Panama City
Tel: 30833
Cable: ELECTRON Panama City

PERU

Fernando Ezeta B.
Avenida Petit Thouars 4719
Miraflores
Casilla 3061
Lima
Tel: 50346
Cable: FEPERU Lima

PUERTO RICO

San Juan Electronics, Inc.
P.O. Box 5167
Ponce de Leon 154
Pda. 3-Pta. de Tierra
San Juan, P.R. 00906
Tel: (787) 725-3342
Cable: SATRONICS San Juan

URUGUAY

Pablo Ferrando S.A.
Comercial e Industrial
Avenida Italia 2877
Casilla de Correo 370
Montevideo
Tel: 40-3102
Cable: RADIUM Montevideo

VENEZUELA

Hewlett-Packard De Venezuela
C.A.
Edificio Arisán Office No. 6
Avda. Francisco de Miranda
Apartado del Este 10934
Chacaltó
Caracas
Tel: 71.88.05, 71.88.69, 71.88.76
Cable: HEWPAK Caracas

FOR AREAS NOT LISTED, CONTACT:

Hewlett-Packard Inter-Américas
3200 Hillview Ave.
Palo Alto, California 94304
Tel: (415) 326-7000
TWX: 910-373-1267
Cable: HEWPAK Palo Alto
Telex: 034-8461



ELECTRONIC INSTRUMENTATION SALES AND SERVICE EUROPE, AFRICA, ASIA, AUSTRALIA

EUROPE

AUSTRIA

Unilabor GmbH
Wissenschaftliche Instrumente
Rummelhardgasse 6/3
P.O. Box 33
Vienna IX/71
Tel: 426 181
Cable: LABORINSTRUMENT Vienna

BELGIUM

Hewlett-Packard Benelux S.A.
348 Boulevard du Souverain
Brussels 16
Tel: 72 22 40
Cable: PALOBEN Brussels
Telex: 23 494

DENMARK

Hewlett-Packard A/S
Langebjerg 6
2850 Naerum
Tel: 01 80 40 40
Cable: HEWPACK AS
Telex: 66 40

FINLAND

Hewlett-Packard Oy
Gyldenintie 3
Helsinki 20
Tel: 67 35 38
Telex: 12-1563

FRANCE

Hewlett-Packard France
150 Boulevard Masséna
75 Paris 13e
Tel: 707 97 19
Cable: HEWPACK Paris
Telex: 25048
Hewlett-Packard France
4, quai des Etoiles
69 Lyon 6e
Tel: 52 35 66
Telex: 31617

GERMANY

Hewlett-Packard Vertriebs-GmbH
Lietzenburger Strasse 30
1 Berlin W 30
Tel: 24 86 36

Hewlett-Packard Vertriebs-GmbH
Herrenberger Strasse 110
703 Böblingen, Württemberg
Tel: 07031 6971
Cable: HEPAG Böblingen
Telex: 72 65 739

Hewlett-Packard Vertriebs-GmbH
Achenbachstrasse 15
4 Düsseldorf 1
Tel: 68 52 58/59
Telex: 85 86 533

Hewlett-Packard Vertriebs-GmbH
Kurfürststrasse 95
6 Frankfurt 50
Tel: 52 00 36
Cable: HEWPACKSA Frankfurt
Telex: 41 32 49

Hewlett-Packard Vertriebs-GmbH
Beim Strohhause 26
2 Hamburg 9
Tel: 24 05 51/52
Cable: HEWPACKSA Hamburg
Telex: 21 53 32

Hewlett-Packard Vertriebs-GmbH
Reginfriedstrasse 13
8 Munich 9
Tel: 69 51 21/22
Cable: HEWPACKSA Munich
Telex: 52 49 85

GREECE

Kostas Karayannis
18, Ermou Street
Athens 126
Tel: 230 301
Cable: RAKAR Athens

IRELAND

Hewlett-Packard Ltd.
224 Bath Road
Slough, Bucks, England
Tel: Slough 28406-9, 29468-9
Cable: HEWPIE Slough
Telex: 84413

ITALY

Hewlett-Packard Italiana S.p.A.
Viale Lunigiana 46
20125 Milan
Tel: 59 15 84
Cable: HEWPACKIT Milan
Telex: 32046

Hewlett-Packard Italiana S.p.A.
Palazzo Italia
Piazza Marconi 25
00144 Rome-Eur
Tel: 591 25 44
Cable: HEWPACKIT Rome

NETHERLANDS

Hewlett-Packard Benelux N.V.
De Boelelaan 1043
Amsterdam, Z 2
Tel: 42 77 77
Cable: PALOBEN Amsterdam
Telex: 13 216

NORWAY

Hewlett-Packard Norge A/S
Nesvæn 13
Havslum
Tel: 53 83 60
Cable: HEWPACK Oslo
Telex: 6621

PORTUGAL

Teletra
Rua Rodrigo da Fonseca 103
P.O. Box 2531
Lisbon 1
Tel: 68 60 72
Cable: TELETRA Lisbon
Telex: 1598

SPAIN

Ataio Ingenieros
Enrique Larreta 12
Madrid, 16
Tel: 235 43 44
Cable: TELETAIO Madrid
Telex: 2 72 49

Ataio Ingenieros
Urgel 259
Barcelona, 11
Tel: 230 69 88

SWEDEN

HP Instrument AB
Sveförsägen 7
Fack
Solna
Tel: 08: 98 12 50
Cable: MEASUREMENTS Stockholm
Telex: 10 721

HP Instrument AB
Hagaensgatan 7
Malmö
Tel: 031 27 68 00

SWITZERLAND

HEWPAK AG
Zürcherstrasse 20
8952 Schlieren Zurich
Tel: 0511 98 18 21
Cable: HEWPAKAG Zurich
Telex: 51933

HEWPAK A.G.
54 Route des Acacias
1211 Geneva 24
Tel: 43 79 29
Telex: 2 24 86

TURKEY

Telekom Engineering Bureau
P.O. Box 376 Galata
Istanbul
Tel: 49 40 40
Cable: TELEMATON Istanbul

UNITED KINGDOM

Hewlett-Packard Ltd.
225 Bath Road
Slough, Bucks
Tel: Slough 28406-9, 29486-9
Cable: HEWPIE Slough
Telex: 84413

YUGOSLAVIA

Belram S.A.
83 Avenue des Mimosas
Brussels 15, Belgium
Tel: 34 33 32
Cable: BELRAMEL Brussels
Telex: 21790

FOR AREAS NOT LISTED, CONTACT:

Hewlett-Packard S.A.
54 Route des Acacias
1211 Geneva, Switzerland
Tel: 0221 42 81 50
Telex: 2 24 86
Cable: HEWPACKSA Geneva

AFRICA, ASIA, AUSTRALIA

AUSTRALIA

Hewlett-Packard Australia Pty. Ltd.
22-26 Weir Street
Glen Iris 3146
Victoria
Tel: 20 1371 (4 lines)
Cable: HEWPAK Melbourne

Hewlett-Packard Australia Pty. Ltd.
61 Alexander Street
Crows Nest 2065
New South Wales
Tel: 43 7866
Cable: HEWPAK Sydney

Hewlett-Packard Australia Pty. Ltd.
97 Churchill Road
Prospect 5082
South Australia
Tel: 65 2366
Cable: HEWPAK Adelaide

CEYLON

United Electronics Ltd.
P.O. Box 681
Yahala Building
Staples Street
Colombo 2
Tel: 5496
Cable: HOTPOINT Colombo

ETHIOPIA

African Salespower & Agency
Private Ltd., Co.
P.O. Box 718
58/59 Cunningham Street
Addis Ababa
Tel: 12285
Cable: ASACO Addisababa

HONG KONG

Schmidt & Co. (Hong Kong) Ltd.
P.O. Box 297
1511, Prince's Building
15th Floor
10, Chater Road
Hong Kong
Tel: 240168, 232735
Cable: SCHMIDTCO Hong Kong

INDIA

The Scientific Instrument Co., Ltd.
6, Tel Bahadur Sapru Road
Allahabad 1
Tel: 2451
Cable: SICO Allahabad

The Scientific Instrument Co., Ltd.
240, Dr. Dadabhai Naoroji Road
Bombay 1
Tel: 26 2642
Cable: SICO Bombay

The Scientific Instrument Co., Ltd.
11, Esplanade East
Calcutta 1
Tel: 23 4129
Cable: SICO Calcutta

The Scientific Instrument Co., Ltd.
30, Mount Road
Madras 2
Tel: 86339
Cable: SICO Madras

The Scientific Instrument Co., Ltd.
B-7, Ajmeri Gate Extn.
New Delhi 1
Tel: 27 1053
Cable: SICO New Delhi

IRAN

Telecom Ltd.
P.O. Box 1812
240 Kh. Saba Shomali
Teheran
Tel: 48111, 43850
Cable: BASCOM Teheran

ISRAEL

Electronics & Engineering
Division of Motorola Israel Ltd.
16, Kremenetski Street
Tel Aviv
Tel: 35021 (four lines)
Cable: BASTEL Tel-Aviv

JAPAN

Yokogawa-Hewlett-Packard Ltd.
Nisei Ibaragi Bldg
2-2-8, Kasuga
Ibaragi-shi
Osaka
Tel: 0726-23-1641

Yokogawa-Hewlett-Packard Ltd.
Ito Building
No. 59, Kotoricho
Nakamura-ku, Nagoya City
Tel: 551-0215

Yokogawa-Hewlett-Packard Ltd.
Ohashi Building
No. 59, 1-chome, Yoyogi
Shibuya-ku, Tokyo
Tel: 370-2281
Telex: YHPMARKET TOK 23-724

KENYA

R. J. Tilbury Ltd.
P.O. Box 2754
Suite 517 518
Hotel Ambassador
Nairobi
Tel: 25670, 26803, 68206, 58196
Cable: ARIAYTEE Nairobi

KOREA

American Trading Co., Korea, Ltd.
Seoul P.O. Box 1103
112-35 Sokong Dong
Jung-ku, Seoul
Tel: 3,7049, 3,7613
Cable: AMTRACO Seoul

LEBANON

Constantin E. Macridis
Clemenceau Street
Clemenceau Center
Beirut
Tel: 220846
Cable: ELECTRONUCLEAR Beirut

MALAYSIA

Mecomb Malaysia Ltd.
2 Lorong 13-6A
Section 13
Petaling Jaya, Selangor
Cable: MECOMB Kuala Lumpur

NEW ZEALAND

Hewlett-Packard (N.Z.) Ltd.
32-34 Kent Terrace
P.O. Box 9443
Wellington, N.Z.
Tel: 56-409
Cable: HEWPACK Wellington

PAKISTAN (EAST)

Mushko & Company, Ltd.
31, Innah Avenue
Dacca
Tel: 80058
Cable: NEWDEAL Dacca

PAKISTAN (WEST)

Mushko & Company, Ltd.
Osman Chambers
Victoria Road
Karachi 3
Tel: 51027, 52927
Cable: COOPERATOR Karachi

SINGAPORE

Mechanical & Combustion
Engineering Company Ltd.
9, Jalan Kilang
Singapore 3
Tel: 642361-3
Cable: MECOMB Singapore

SOUTH AFRICA

F. H. Flinter & Co. (Pty.), Ltd.
Hill House
41 Somerset Road
Cape Town
Tel: 2 9711
Cable: AUTOPHONE Cape Town
Telex: 7038CT

F. H. Flinter & Co. (Pty.), Ltd.
607, Pharmacy House
80 Jorissen Street
Braamfontein, Johannesburg
Tel: 724-4172
Telex: 0026 JHB

TAIWAN

Hwa Sheng Electronics Co. Ltd.
P.O. Box 1558
21 Nanking West Road
Taipei
Tel: 66076, 45936, 48661
Cable: VICTRONIX Taipei

THAILAND

The International Engineering
Co., Ltd.
P.O. Box 39
614 Sukhumvit Road
Bangkok
Tel: 910722 (7 lines)
Cable: GYSOM Bangkok

VIETNAM

Landis Brothers & Company, Inc.
P.O. Box H-3
216, Hien-Vuong
Saigon
Tel: 20 805
Cable: LANBROCOMP Saigon

ZAMBIA

R. J. Tilbury (Zambia) Ltd.
P.O. Box 2792
Lusaka
Zambia, Central Africa

FOR AREAS NOT LISTED, CONTACT:

Hewlett-Packard Export Marketing
1501 Page Mill Road
Palo Alto, California 94304
Tel: (415) 326 7000
TWX: 910-373-1267
Telex: 034 8461
Cable: HEWPACK Palo Alto



PART NO. 09100-90001